

Sangoma Handsets Default login

Article Number: 164 | Rating: 5/5 from 1 votes | Last Updated: Thu, Oct 5, 2017 at 11:55 AM

The default login details for a default Sangoma handset is;

Username: admin

Password: admin

This should be the default password for handsets out of the box or after a factory reset, please note that these handsets support zero touch and if purchased via us they will most likely upon first boot or reset just connect directly to your PBX and the password will change to your PBX systems password. This will be the password you have specified for handset admin and user access see steps below;

talk

Modules

Basic Mode

Dashboard

UCP

End

Glo

Inte

Ext

Port

Admin

Administrators

Asterisk CLI

Asterisk Modules

Backup & Restore

Blacklist

Bria Cloud Solutions

Bulk Handler

CID Superfecta

CallerID Lookup Sources

Certificate Management

REST API

RMS Management

Sound Languages

System Admin

System Recordings

User Management

XMPP

XactViewV3 Admin

Zulu

Applications

Announcements

Follow Me

IVR

Languages

Misc Applications

Misc Destinations

Paging and Intercom

Park and Announce

Parking

Queue Callback

Queue Priorities

Queues

Plan Queue

DAHDI Channel DIDs

DAHDI Config

Firewall

Inbound Routes

Outbound Call Limit

Outbound Routes

SIPSTATION

Trunks

Reports

Asterisk Info

Asterisk Logfiles

Weak Password Detection

Settings

Advanced Settings

Asterisk IAX Settings

Asterisk Logfile Settings

Asterisk Manager Users

Asterisk REST Interface Users

Asterisk SIP Settings

CRM Settings

EndPoint Manager

Fax Configuration

talk

Modules

Basic Mode

Dashboard

UCP

EndPoint Manager

About Endpoint Manager

This module is used to automatically provision & configure Desk Phones, Wireless Phones, Door Phones, Overhead Paging Devices, Gateways, and Specialty devices from supported manufacturers.

For information and instructions on using Endpoint Manager, please see the Endpoint Manager Wiki .

To get started please choose an option in the Menu on the right.

EndPoint

Global Settings

Extension Mapping

Brands

Then in the next screen add your desired passwords that your handsets will be set to;

talk

Modules

Basic Mode

Dashboard

UCP

EndPoint Manager

Global Settings

Internal Address

External Address

Ports

Phone Admin Password

Phone User Password

ReSync Time

XML-API (RestAPI) Default Login

Extension Mapping IP Addresses

Extension Mapping Phone Status

Value Correction

Admin UCP for All

pbxXXXXXXXXX.ic-talk.co.uk

HTTP Provisioning Port

Secure HTTPS Provisioning Port

RESTfull Apps Port

Secure RESTfull Apps Port

123456

7890

86400

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Authentication of HTTP or HTTPS provisioning requests from endpoints is currently enabled. Configuration of provisioning ports and credentials is done through Sysadmin Provisioning Management .

The username that is currently configured for HTTP and HTTPS provisioning is 'XXXXXXXXXX' and the password is 'XXXXXXXXXX' (without quotes).

Save Global

Posted by: Jonathan - Wed, Sep 13, 2017 at 5:50 PM. This article has been viewed 10886 times.

Online URL: <https://kb.ic.uk/article/sangoma-handsets-default-login-164.html> (<https://kb.ic.uk/article/sangoma-handsets-default-login-164.html>)