


# FTTC Managed Install Zyxel Router Configuration

Before you start to configure the router. Please see the Article "How to locate your configuration sheet". Once you have read and followed the steps in that article, you can proceed to configure your router.

1. Log into the device via IP 192.168.1.1 using these details ;username = admin Password = 1234





2. Change the admin password to the password on the configuration sheet.
3. Hover over network settings, and go to Broadband.



4. On ETH WAN, click modify on the far right.

Add New WAN Interface

| # | Name   | Type | Mode    | Encapsulat... | 802.1p | 802.1q | IgmpProxy | NAT | Default Gat... | IPv6 | MLD Proxy | Modify  |
|---|--------|------|---------|---------------|--------|--------|-----------|-----|----------------|------|-----------|---|
| 1 | ADSL   | ATM  | Routing | IPoE          | N/A    | N/A    | Y         | Y   | Y              | N    | N         |   |
| 2 | VDSL   | PTM  | Routing | PPPoE         | 0      | 101    | Y         | Y   | Y              | N    | N         |   |
| 3 | ETHWAN | ETH  | Routing | IPoE          | N/A    | N/A    | Y         | Y   | Y              | N    | N         |   |

5. Change encapsulation to PPPoE.
6. Enter the PPP username and password, this will be on the configuration sheet.

**WAN Interface Edit**

**General**

Name: ETHWAN  
 Type: Ethernet  
 Mode:  Routing  Bridge  
 Encapsulation: PPPoE  
 IPv4/IPv6 Mode: IPv4 Only

**PPP Information**

PPP User Name:   
 PPP Password:   
 password unmask  
 PPP Connection Trigger:  Auto Connect  On Demand  
 PPPoE Passthrough:  Enable  Disable

**IP Address**

Obtain an IP Address Automatically  
 Static IP Address

**VLAN**


Active:  Enable  Disable  
 802.1p: 0  
 802.1q:  (0~4094)

OK Cancel

7. Go to the Ethernet WAN tab at the top, enable LAN4 port as ETH WAN, apply.
8. Ensure that "apply as default gateway" option is selected.

Now you have completed the network setup, all that is left is end user settings and remote management.

1. 1. Hover over Maintenance, and go to Remote Management.



2. Click all of the trust domains for every port and APPLY.

| service | LAN/WLAN                                   | WAN                             | Trust Domain                               | Port |
|---------|--|---------------------------------|--|------|
| HTTP    | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 80   |
| HTTPS   | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 443  |
| FTP     | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 21   |
| TELNET  | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 23   |
| SSH     | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 22   |
| SNMP    | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable | 161  |
| PING    | <input checked="" type="checkbox"/> Enable | <input type="checkbox"/> Enable | <input checked="" type="checkbox"/> Enable |      |

Apply Cancel

You have now completed the steps to configuring your router.

Posted by: Wayne Coulthard - Mon, Aug 14, 2017 at 3:22 PM. This article has been viewed 5252 times.

Online URL: <https://kb.ic.uk/article/fttc-managed-install-zyxel-router-configuration-144.html> (<https://kb.ic.uk/article/fttc-managed-install-zyxel-router-configuration-144.html>)