

Sangoma Handsets Default login


Article Number: 164 | Rating: 5/5 from 1 votes | Last Updated: Thu, Oct 5, 2017 at 11:55 AM

The default login details for a default Sangoma handset is;

Username: admin

Password: admin

This should be the default password for handsets out of the box or after a factory reset, please note that these handsets support zero touch and if purchased via us they will most likely upon first boot or reset just connect directly to your PBX and the password will change to your PBX systems password. This will be the password you have specified for handset admin and user access see steps below;



Then in the next screen add your desired passwords that your handsets will be set to;

Endpoint Manager

Global Settings

Internal Address

External Address

Ports		
HTTP Provisioning Port	<input type="text" value="[REDACTED]"/>	Firewall Zone(s): Internal, Other
Secure HTTPS Provisioning Port	<input type="text" value="[REDACTED]"/>	Firewall Zone(s): Internal, Other
RESTfull Apps Port	<input type="text" value="[REDACTED]"/>	Firewall Zone(s): Internal
Secure RESTfull Apps Port	<input type="text" value="[REDACTED]"/>	Firewall Zone(s): Internal

Authentication of HTTP or HTTPS provisioning requests from endpoints is currently **enabled**. Configuration of provisioning ports and credentials is done through Sysadmin Provisioning Management .
The username that is currently configured for HTTP and HTTPS provisioning is '[REDACTED]' and the password is '[REDACTED]' (without quotes).

Phone Admin Password

Phone User Password

ReSync Time Sec

XML-API (RestAPI) Default Login Yes No

Extension Mapping IP Addresses Yes No

Extension Mapping Phone Status Yes No

Value Correction Yes No

Admin UCP for All Yes No

> Save Global

Posted by: Jonathan - Wed, Sep 13, 2017 at 5:50 PM. This article has been viewed 8120 times.

Online URL: <https://kb.ic.uk/article/sangoma-handsets-default-login-164.html>