


Handset Registration - W56/W60

Follow these steps to register your additional handsets to your base station.

When the handset LCD screen prompts "Unregistered!", press an hold  on the base station until the registration LED indicator flashes. There are two methods to register a new handset:

Easy Registration

1. Press the Reg soft key on the handset to register quickly.

Normal Registration

1. Press the OK soft key on the handset, and then select Register Handset.
2. Select the desired base station and then press the OK soft key. The handset begins searching for the base station.
3. Press the OK soft key after finding a base station successfully.
4. Enter the base station PIN (default: 0000), and then press the Done soft key to complete registration.

Handset Name

To rename the handset:

1. Press the OK key to enter the main menu, and then select Settings->Handset Name.
2. Edit the value in the Rename field.
3. Press the Save soft key to accept the change.

Posted by: Darren M - Wed, Jan 27, 2021 at 9:53 AM. This article has been viewed 2379 times.

Online URL: <https://kb.ic.uk/article/handset-registration-w56-w60-276.html> (<https://kb.ic.uk/article/handset-registration-w56-w60-276.html>)